



install.

1. Attach the OBD cable and antenna cables to the **Sentinel** device, and plug into the OBD port located on or under the dash near the steering column.
2. Choose a safe mounting location left of the steering column. Clean area with the alcohol wipe and let dry.
3. Apply the Velcro backing to the cleaned area, then mount the Sentinel Device.
4. Peel the adhesive backing off the antenna and mount on the top left side of the dashboard. Safely tuck the cables below the dashboard.



set up.

1. Go to www.drivewithsentinel.com and click Login in the upper right corner of the screen.
2. Enter provided username and password.
3. First-time users will be taken directly to the Account Page to enter or confirm information, then click the Save button.
4. Click the Text Link To Phone button to send a link for the mobile dashboard to your phone number(s).



monitor.

KNOW AT A GLANCE:

- If any cell phone use has been logged
- If any speeding violation has been logged
- Vehicle location
- If any unauthorized use has been logged
- If the engine is ON or OFF

COMMUNICATE WITH DRIVER

Notify driver via desktop, tablet or smartphone to:

- Turn phone on immediately
- Pull over to a safe location



VRM Telematics

DISTRACTED DRIVING SOLUTIONS

(601) 728-1403

support@drivewithsentinel.com

www.drivewithsentinel.com



contents.

Sentinel Device • OBD Cable • Antenna • Alcohol Wipe • Velcro •

Limited One Year Warranty

Sentinel makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 1 year from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. **THIS WARRANTY IS**

EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.